
technicalnote

Seismic Perimeter Details


Installation Details: Chicago Metallic 1496 Seismic Perimeter Clip

For more installation details, reference ROCKFON's ICCES document, ESR-2631. Qty:1 #7, 7/16" sharp point screw is required in the inner hole to secure the clip to the wall angle for all shadowline wall enclosures. All other details installed per ASTM E580. Consult with local engineer of record or authority having jurisdiction to verify compliance for your project.




Screw location for Shadowline

1496 with 1420 Wall Angle: Square Edge Panels




1496 with 1420 Wall Angle: Reveal Panels






Seismic Perimeter Details

1496 with 1468 Shadowline with Reveal Panels




1496 with 1469 Shadowline with Reveal Panels




Seismic Perimeter Details

1496 with 1467 Wall Angle: Reveal Panels



1496 with 1464.905 Shadowline with Reveal Panels



Have questions?

Contact the ROCKFON Technical Services Team by calling 800-323-7164, prompt 3 and we can provide assistance on your project.



ROCKFON 4849 SOUTH AUSTIN AVE., CHICAGO, IL 60638 / USA and Canada: 800-323-7164 / Fax: 800-222-3744 / rockfon.com